



Actuator for Hasselblad V lenses

User Manual



Please follow these instructions carefully when using the actuator:



- 1) Check that the shutter of the Hasselblad lens is loaded, otherwise load it with a flat screwdriver by mean of the special small wheel.
- 2) Load the Silvestri trigger system until the loading lever arrives to the end of its run.
- 3) It is only possible to attach the lens under these conditions, even if it fits in, it will not function.
- 4) Insert the lens on the loading system aligning the red dots.
- 5) Connect a cable release.
- 6) Make a single pressure on the cable release, the shutter will close when releasing this pressure.
- 7) Make a second pressure, the shutter will then perform the exposure time set on the lens.

